Interface Leads

Made in Denmark by
Kram Telecom A/S

Interface Leads

Instruction for

VDA cable 68740 for
Saab / Opel / Vauxhall

Made in Denmark by
Kram Telecom A/S

EN740

Interface Leads

Product description

VDA cable 68740 for
Saab / Opel / Vauxhall

Interface Leads are used for car stereos with a Line-In function or VDA preparation. It enables the use of the car speakers when answering/making calls from your cell phone. Thereby using the radios build-in mute function.

Speaker-function: This is achieved by connecting the carkit directly to the cars Line-In input/VDA connector. By using the radios built-in relays the telephone conversation is send through the car speakers while the radio is muted. This way you will achieve a perfect hands free sound without interference from the car radio.

For a complete cable-set two item no. is required. The first is a car-specific Interface Lead. The second is a carkit-specific Interface adaptor cable .

Power supply of the carkit: All Interface Leads are delivered with a power connector for the carkit, that way you avoid cutting the cars wiring loom.

Please check the radio instruction manual for special issues regarding the connection and set-up of the radio, when connecting a carkit.

See our complete Interface program on
www.kram.dk

Interface Leads

Installation description

VDA cable 68740 for
Saab / Opel / Vauxhall

Connect the VDA cable to the VDA connector. The VDA connector is normally found behind the passenger side kick panel (LHD), behind glove compartment or climacontrol panel. Connect the other end through a carkitspecific interface adaptor to the carkit.

SAAB 9.3 normally has the VDA plug placed behind the passenger kick panel on the center consol. The plug is wrapped in tape.



SAAB 9.5 normally has the VDA plug placed behind the Heater control panel. The plug is wrapped in tape and is taped together with other cables and can therefore be hard to spot.

After the installation you must adjust the phone volume to its middle position and then adjust the conversation sound level according to the description in the radio manual.

When the VDA cable is installed it will redirect your call through the cars front speaker.

Please remember to use a carkit interface adaptor cable to connect the carkit to the VDA cable.